



SONIXX


X-SPRINT

USER GUIDE

CHOOSE THE RIGHT EAR TIPS




For the best music experience it is important the earphones are fitted correctly. Included with the X-Sprint are three assorted sized pairs of ear tips (small, medium, large) and a pair of double flanged eartips. Try each set until you found the fit that is right for you and the sound performs best.



MEMORY WIRE: FIRST USE



When you first receive the X-Sprint the memory wire should be straight. Place the earphones into your ears first as shown in the diagram, make sure you are happy with the tips and fit.



Bend the memory wire back around your ear



The cable should hang down behind your ear and the fit should be comfortable and secure

SUPPORT AND WARRANTY

For best care of your earphones, please use the included carry case to protect the earphones when not in use.

The X-Sprint come with a 3 year warranty

Please contact us at www.sonixx.co.uk for any support or warranty issues